Exterior Body Parts

Removal/Installation

NOTE:

- To adjust the hood, door and trunk lid alignment, refer to the Accord Service Manual.
- Before adjusting the door and door hinges, replace the mounting bolts.

Mounting bolts/nuts Torque:
6 X 1.0 mm: 9.8 N-m (1.0 kgf-m, 7.2 lbf-ft)
8 X 1.25 mm: 22 N-m (2.2 kgf-m, 16 lbf-ft)
*8 X 1.25 mm: 28 N-m (2.9 kgf-m, 21 lbf-ft)

▶: Sealing locations
NOTE: Seal the following areas to prevent water leak and rust.
Mastic sealer: 3M #08654 or equivalent.